

Bergdahl Associates, Inc. 2990 Sutro Street Reno, NV 89512-1616 775-323-7542 775-323-7595 fax www.bergdahl.com

Technical Data Sheet

Description

eOx Oxygen is a powerful cleaner specifically designed to clean oxygen handling equipment or in applications where there must be zero trace hydrocarbons, ie. Fuel Cells. It removes all kinds of oil, grease and dirt from surfaces without effort. eOx Oxygen's performance surpasses other alkaline cleaning agents due to its faster and more intensive action. It removes unpleasant odors and has a fresh smell. eOx leaves the cleaned surface antistatic which helps the surface stay clean longer. eOx is specially designed to meet stronger local legislations, is solvent free and human and wastewater friendly. Although this product has a high pH (12.8), which gives it an excellent and strong cleaning affect, it does not affect metals; including aluminium as it is inhibited for this use.

Advantages

- Non-toxic
- Non-flammable
- Non-hazardous Not subject to dangerous goods regulations.
- No phosphates, acids or silicones and is non-butyl.
- Very economical to use.
- Fast, intense cleaning action surpasses other cleaners' performance.
- Cleaned surfaces become slightly *antistatic* for up to 4 weeks.
- Can be effective used as a spray-on & wipe-off process.
- Safe for use in high-pressure washers, immersion systems and ultrasonic machines.
- High biodegradability (tested by the University of Ghent, Belgium)
- Quickly de-emulsifies, resulting in excellent oil and water separation
- Fresh smell NOT citrus
- Safe to use on all metals, plastics, lacquer paints, floors, walls, ceilings, etc

Application

eOx Oxygen may be safely used in cleaning fountains, immersion or ultrasonic baths, parts washers, high-pressure cleaners, and other industrial cleaning machines. It is safe to use on all metals, plastics, lacquer paints, floors, walls, ceilings, etc.

Directions for Use

- Whatever system is used for cleaning with eOx Oxygen, a mechanical action (brush, sponge, aeration of solution, ultrasonic, etc.) is <u>required</u> to break the surface tension of the dirt. Just soaking for an extended time will **not** be sufficient for cleaning.
- eOx Oxygen is not flammable and can be safely heated. For immersion or ultrasonic baths we recommend 50° C/122° F to minimize the evaporation rate.
- eOx Oxygen is highly concentrated. If the product is not sufficiently diluted, a white haze or stripes can be left after drying especially on very smooth or shiny surfaces. This haze will disappear when the surface is treated again with the correct dilution.

• Rinsing all parts, pipes and surfaces is important so no residue remains. Rinsing with warm water is not necessary but will enhance the drying process. If needed, use compressed air to speed up drying time.

Spray the surface to be cleaned with eOx Oxygen diluted at 1:3 with water, brush in, allow a short time for the product to work in (10 seconds), remove dirt by brush. Let it dry. When the cleaned item is to be painted, rinse with plenty water or use eOx Oxygen at a 1:50 dilution.

Package Sizes

1-gallon poly bottles 4 x 1-gallon cases 55-gallon poly drums

Shelf Life

4-years

<u>Storage</u>

Do not store under 35°F/2C and not above 122°F/50C. Do not use below 35°F/2C.

Properties

NFPA Hazaro	d Class:	Health Flammability Reactivity	0 (as used) 0 0
VOC:	<1 g/L (as used)		

pH: 12.9 (concentrate) Flash point: None

Bergdahl Associates, Inc · 775-323-7542 · info@bergdahl.com · www.bergdahl.com

Disclaimer: Bergdahl Associates, Inc. believes the information contained herein is accurate; however, makes no guarantees with respect to such accuracy and assumes no liability in connection with the use of the information contained herein by any party. The provision of the information contained herein and the provision of information by or reliance on Bergdahl Associates, Inc. Technical and Environmental Services Department is not intended to be and should not be construed as legal advice or as ensuring compliance with any country, federal, state, or local laws and regulations. 07/2011